IMPROVING DAMAGED SOIL IN THE OIL FIELD

Practical Approaches to Oil-Contaminated Soil Remediation and Restoration

Sustainable Soil Remediation, Rehabilitation and Environmental Recovery

Presented by:
ATCO GAS OIL SERVICES LTD

Focus Areas:
Oil Spill Response | Soil Remediation | Bioremediation | Soil Restoration | Environmental Protection.

INTRODUCTION

Oil-field operations can damage soil through:

- Crude-oil spills and leaks
- Produced-water releases
- Fuel and lubricant spills
- Pipeline failures
- Well-site activities
- Drilling-fluid and waste handling
- Improper disposal of petroleum-contaminated materials
- Heavy vehicle and equipment movement
- Storage-tank leaks

Petroleum hydrocarbons can reduce soil quality, interfere with plant growth, affect soil microorganisms and create pathways for contamination of surface water and groundwater.

The objective of remediation is therefore not simply to remove oil, but to restore the soil to a safe and functional condition.

WHAT HAPPENS TO SOIL AFTER OIL CONTAMINATION?

Oil contamination can change the physical, chemical and biological properties of soil.

Physical impacts

- Soil pores become blocked by hydrocarbons.
- Water infiltration may decrease.
- Soil structure can deteriorate.
- Surface crusting may occur.

Chemical impacts

- Total Petroleum Hydrocarbons (TPH) increase.
- BTEX compounds may be present.
- Soil pH and nutrient balance can be affected.
- Some contaminants may migrate toward groundwater.

Biological impacts

- Beneficial soil microorganisms may be inhibited.
- Plant germination and root development can be reduced.
- Soil biodiversity may decline.

FIRST PRIORITY: STOP THE SOURCE

Before attempting to restore damaged soil, the contamination source must be controlled.

Immediate actions

1. Identify the source of contamination.
2. Stop the leak or discharge.
3. Isolate the affected area.
4. Recover free-standing oil where practicable.
5. Prevent migration into drainage channels and water bodies.
6. Establish temporary containment.
7. Protect workers and nearby communities.

Key principle:

Do not remediate continuously contaminated soil while the source of contamination remains active.

Environmental cleanup guidance recommends source control and site stabilization before selecting the long-term remediation technology.

SITE ASSESSMENT AND SOIL CHARACTERIZATION

A proper remediation program begins with understanding the contaminated site.

Conduct:

- Site inspection and mapping
- Contamination-depth assessment
- Soil sampling
- Laboratory analysis
- Groundwater assessment where required
- Soil texture analysis
- pH testing
- Moisture assessment
- Nutrient analysis
- TPH analysis
- BTEX analysis where relevant
- Metals analysis where potential sources indicate a concern

Important question:

What contaminants are present, at what concentration, and how far have they migrated?

Remediation technology should be selected based on contaminant characteristics, soil properties, site conditions and cleanup objectives.

ESTABLISH THE REMEDIATION TARGET

Before treatment begins, establish measurable cleanup criteria based on:

- Applicable environmental regulations

- Site-specific risk assessment
- Intended future land use
- Soil and groundwater protection requirements
- Human-health and ecological considerations
- Project-specific environmental standards

Typical monitoring parameters

Chemical

- TPH
- BTEX
- PAHs where relevant
- Metals where relevant
- pH

Physical

- Moisture
- Soil texture
- Compaction
- Infiltration

Biological

- Microbial activity
- Vegetation recovery
- Soil fertility indicators

REMEDIATION TECHNOLOGY OPTIONS

There is no single solution for every oil-contaminated site.

Major options include:

1. Mechanical recovery
2. Excavation and replacement
3. Landfarming

4. Biopiles
5. In-situ bioremediation
6. Bioventing
7. Soil washing
8. Thermal treatment
9. Chemical treatment
10. Phytoremediation
11. Natural attenuation, where scientifically and regulatorily appropriate

Bioremediation uses microorganisms to degrade organic contaminants in soil and groundwater and can be implemented either in place or after excavation. (US EPA)

LANDFARMING

What is landfarming?

Landfarming is an ex-situ biological treatment method in which contaminated soil is spread in a controlled treatment area and periodically aerated, conditioned and monitored to encourage microbial degradation of petroleum hydrocarbons.

Basic process

Excavate → Transport → Spread → Aerate → Add nutrients if required → Control moisture → Monitor → Repeat → Verify

Landfarming can be relatively simple and cost-effective, but it requires sufficient treatment area and may be unsuitable for very high contamination, significant metals contamination or conditions where leaching and vapor emissions cannot be adequately controlled.

BIOREMEDIATION

Bioremediation uses naturally occurring or introduced microorganisms to break down petroleum hydrocarbons.

Two important approaches

Biostimulation

- Improves conditions for naturally occurring microorganisms.

- May involve appropriate nutrient, oxygen and moisture management.

Bioaugmentation

- Introduces selected microorganisms capable of degrading specific contaminants.

In many petroleum-contaminated soils, optimizing environmental conditions such as oxygen availability, moisture, pH, nutrients and temperature is fundamental to improving biodegradation.

BIOPILE REMEDIATION

A biopile is a controlled pile of excavated contaminated soil designed to improve biological degradation.

Main components

- Contaminated soil
- Impermeable base/liner where required
- Aeration system
- Moisture-management system
- Nutrient application
- Gas/vapor controls where required
- Monitoring points

Advantages

- Better process control than open landfarming
- Requires less land area
- Can improve oxygen delivery
- Suitable for controlled treatment of excavated soil

IN-SITU BIOREMEDIATION

In-situ treatment means treating contaminated soil without excavating the entire affected area.

Possible techniques

- Biostimulation
- Bioventing
- Oxygen delivery
- Nutrient amendment
- Controlled moisture management
- Other site-specific biological enhancement methods

Advantages

- Less excavation
- Reduced transportation
- Lower disturbance to the site
- Potentially lower project cost

Limitations

- Difficult mixing in heterogeneous soils
- Variable permeability
- Difficult contaminant distribution
- Requires detailed site characterization

In-situ methods can be cost-effective, while ex-situ methods such as landfarming and biopiles generally provide greater treatment control but require excavation and handling.

SOIL WASHING

Soil washing is a physical/chemical separation process used to remove or concentrate contaminants from soil.

Basic concept

Excavation → Screening → Washing → Particle separation → Contaminant concentration → Treatment/disposal → Clean soil management

It can be particularly useful where contaminants are concentrated in fine soil fractions.

Soil washing may also be combined with biological treatment for the residual contaminated fraction.

PHYToreMEDIATION

Phytoremediation uses plants and their associated biological processes to assist in reducing or controlling contamination.

Benefits

- Environmentally friendly
- Can improve soil structure
- Helps restore vegetation
- Can reduce erosion
- Supports ecological recovery

Limitations

- Generally slower than intensive physical treatment
- Requires suitable climate and plant species
- Root depth limits treatment
- Not suitable for every contaminant concentration

Phytoremediation should normally be considered as part of an integrated remediation strategy rather than automatically used as the first treatment method.

IMPROVING THE PHYSICAL CONDITION OF DAMAGED SOIL

After petroleum contamination has been reduced, the soil may still require rehabilitation.

Soil improvement measures

- Loosening compacted soil
- Controlled tilling
- Addition of suitable organic matter
- Addition of clean topsoil where necessary
- Restoration of soil structure
- Improving drainage

- Reducing erosion
- Correcting unsuitable pH
- Re-establishing appropriate moisture conditions

The amendment program should be based on laboratory testing rather than indiscriminate addition of materials.

RESTORING SOIL FERTILITY

Remediation should transition from contaminant removal to soil rehabilitation.

Important soil properties

pH
Supports nutrient availability and microbial activity.

Organic matter
Improves soil structure, water retention and biological activity.

Nitrogen and phosphorus
May support microbial processes and vegetation establishment when deficient.

Moisture
Required for microbial activity and plant growth.

Aeration
Provides oxygen required by aerobic hydrocarbon-degrading microorganisms.

Land-treatment guidance emphasizes assessment and management of pH, moisture, nutrients, aeration and other environmental conditions to optimize biodegradation.

EQUIPMENT REQUIRED FOR SOIL REMEDIATION

Site preparation and excavation

- Excavators
- Bulldozers
- Front-end loaders
- Dump trucks
- Graders
- Soil compactors

Soil treatment

- Agricultural/rotary tillers
- Soil mixers
- Aeration equipment
- Irrigation systems
- Water tanks
- Pumps
- Sprayers
- Nutrient application equipment

Environmental monitoring

- Soil sampling tools
- GPS equipment
- Gas/air monitoring instruments
- pH meters
- Moisture meters
- Laboratory testing equipment

Safety and containment

- Spill kits
- Absorbent materials
- Temporary bunds
- Liners
- Drainage controls
- PPE
- Fire extinguishers

OIL RECOVERY AND CONTAMINATION CONTROL

Before biological soil treatment, recover as much free petroleum product as reasonably practicable.

Useful equipment

- Vacuum trucks
- Oil skimmers
- Transfer pumps
- Storage tanks
- Sorbent pads and booms
- Portable containment systems
- Oil-water separators

Objective

Recover → Contain → Separate → Store → Recycle or Manage Waste Safely

This reduces the contaminant load and allows subsequent biological treatment to focus on residual hydrocarbons.

THE ROLE OF SOIL TILLING

Tilling is an important component of controlled land treatment.

Tilling helps to:

- Introduce oxygen
- Improve soil mixing
- Distribute moisture
- Distribute nutrients
- Break up compacted soil
- Increase contact between microorganisms and hydrocarbons

However, excessive tilling can increase dust and vapor emissions and should therefore be performed under appropriate environmental and occupational controls. EPA guidance identifies dust and vapor generation as potential concerns during landfarm aeration.

MOISTURE AND NUTRIENT MANAGEMENT

Microorganisms require suitable environmental conditions to degrade hydrocarbons effectively.

Management approach

Too dry → microbial activity decreases

Too wet → oxygen availability may decrease

Nutrient deficient → biodegradation may become limited

Excess nutrients → unnecessary environmental loading and potential secondary impacts

Therefore:

Apply water and nutrients based on soil testing, treatment objectives and monitoring—not simply by fixed quantities.

ENVIRONMENTAL PROTECTION DURING REMEDIATION

Remediation itself must not create new environmental problems.

Control:

- Stormwater runoff
- Soil erosion
- Dust
- Hydrocarbon vapors
- Leaching
- Contaminated wastewater
- Secondary spills
- Waste generation
- Worker exposure

Treatment areas may require engineered liners, drainage controls and collection systems where there is a risk of contaminant migration.

HEALTH, SAFETY AND ENVIRONMENT (HSE)

Personnel working on contaminated soil may be exposed to petroleum hydrocarbons and other hazards.

HSE requirements

- Conduct risk assessment
- Provide appropriate PPE
- Establish exclusion zones
- Control ignition sources
- Monitor atmospheric conditions where required
- Control dust and vapors
- Provide hygiene facilities
- Train workers
- Maintain emergency response equipment
- Implement waste-management procedures

Minimum PPE may include:

- Safety helmet
- Safety boots
- Chemical-resistant gloves
- Coveralls
- Eye protection
- High-visibility vest
- Respiratory protection where risk assessment requires it

MONITORING THE REMEDIATION PROCESS

Remediation should be managed using data.

Establish a monitoring schedule

Before treatment

- Baseline TPH
- BTEX where relevant
- Soil pH
- Moisture
- Nutrients

- Soil characteristics

During treatment

- TPH trends
- Moisture
- pH
- Nutrients
- Temperature
- Microbial indicators where appropriate
- Air/vapor conditions where relevant

After treatment

- Confirm contaminant concentrations
- Confirm soil quality
- Confirm vegetation establishment
- Verify compliance with applicable cleanup criteria

A successful project should demonstrate measurable contaminant reduction rather than relying only on visual appearance.

QUALITY CONTROL AND LABORATORY TESTING

Representative sampling is critical.

Sampling program should define:

- Sampling locations
- Sampling depth
- Sampling frequency
- Sample preservation
- Laboratory methods
- Quality-control samples
- Data validation
- Reporting requirements

Key principle:

"What is not measured cannot be reliably demonstrated as remediated."

Laboratory results should be compared with the approved remediation targets and baseline conditions.

FINAL SOIL RESTORATION

Once petroleum contamination has been reduced to acceptable levels, restore the soil's physical and ecological function.

Restoration sequence

Confirm cleanup → Improve soil structure → Restore nutrients → Replace topsoil where required → Establish vegetation → Control erosion → Monitor recovery

Suitable vegetation should be selected according to:

- Local climate
- Soil conditions
- Native ecology
- Intended land use
- Rooting characteristics
- Water availability

INTEGRATED REMEDIATION STRATEGY

For many oil-field sites, the best approach is a combination of technologies.

Example strategy

1. Source control
↓
2. Containment
↓
3. Free-oil recovery
↓
4. Site characterization
↓

5. Excavation where necessary

↓

6. Landfarming / biopile / in-situ treatment

↓

7. Soil conditioning

↓

8. Laboratory verification

↓

9. Soil restoration

↓

10. Vegetation establishment

↓

11. Long-term monitoring

This approach allows treatment to be matched to the actual contamination conditions.

HOW TO SELECT THE RIGHT TECHNOLOGY

Consider:

Factor	**Question**
Contamination level	How heavily contaminated is the soil?
Hydrocarbon type	Light oil, crude oil, diesel or weathered hydrocarbons?
Soil type	Sand, clay, silt or mixed soil?
Depth	Is contamination shallow or deep?
Groundwater	Is groundwater at risk?
Land availability	Is there enough space for treatment?
Climate	Will temperature and rainfall support treatment?
Time	How quickly must the site be restored?
Cost	What is economically achievable?
Regulation	What cleanup criteria apply?
Future land use	Agriculture, industrial use, habitat or other?

COMMON MISTAKES TO AVOID

Do not:

- Simply cover contaminated soil with clean soil.
- Treat soil without stopping the contamination source.
- Apply excessive fertilizers without testing.
- Flood contaminated land.
- Burn contaminated soil indiscriminately.
- Spread contaminated soil into clean areas.
- Ignore groundwater pathways.
- Rely only on visual inspection.
- Dispose of contaminated soil without proper authorization.
- Declare a site clean without laboratory verification.

Remember:

Remediation must remove or reduce risk—not simply hide contamination.

SUCCESS INDICATORS

A successful soil-restoration project should demonstrate:

Environmental success

- Reduced petroleum contamination
- No uncontrolled migration
- Protection of groundwater and surface water
- Improved soil quality
- Re-established vegetation

Operational success

- Effective treatment process

- Controlled waste generation
- Safe working conditions
- Reliable monitoring data

Long-term success

- Stable soil conditions
- Sustainable vegetation
- No significant contaminant rebound
- Compliance with applicable environmental requirements

RECOMMENDED FIELD APPROACH

A practical oil-field remediation program should follow five phases:

PHASE 1 — ASSESS
Identify contamination and determine its extent.

PHASE 2 — CONTROL
Stop the source and prevent further migration.

PHASE 3 — REMEDIATE
Select and implement the most appropriate treatment technology.

PHASE 4 — RESTORE
Rebuild soil structure, fertility and vegetation.

PHASE 5 — VERIFY
Use laboratory and field monitoring to demonstrate that cleanup objectives have been achieved.

CONCLUSION

Damaged soil in an oil field can be successfully improved when remediation is approached as a complete environmental engineering process.

The key principles are:

STOP THE SOURCE
CONTAIN THE CONTAMINATION
RECOVER FREE OIL
CHARACTERIZE THE SOIL

SELECT THE RIGHT TECHNOLOGY
OPTIMIZE BIOLOGICAL ACTIVITY
MONITOR THE RESULTS
RESTORE SOIL FUNCTION
VERIFY COMPLIANCE

Bioremediation, landfarming, biopiles, soil washing, bioventing and other technologies can each have an important role, but technology selection must be based on site-specific conditions rather than a one-size-fits-all approach.

FINAL MESSAGE

"Effective oil-field remediation does not end when the oil disappears. It ends when the soil is safe, functional, stable and capable of supporting its intended future use."

RECOMMENDED IMPLEMENTATION FRAMEWORK

For an oil-field operator:

Environmental Baseline Study
↓
Contamination Mapping
↓
Risk Assessment
↓
Remediation Action Plan
↓
Technology Selection & Treatability Testing
↓
Pilot Treatment
↓
Full-Scale Remediation
↓
Laboratory Verification
↓
Soil Rehabilitation
↓
Vegetation & Ecological Restoration
↓
Post-Remediation Monitoring

Treatability testing is particularly valuable where weathered hydrocarbons or difficult soil conditions may limit the effectiveness of conventional biological treatment.

CLOSING

PROTECTING THE SOIL TODAY

PROTECTS THE OIL FIELD AND COMMUNITY TOMORROW.

Sustainable Petroleum Operations Require:

Responsible Production + Effective Spill Response + Scientific Remediation + Soil Restoration + Continuous Environmental Monitoring